



Box 459 - Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823

Thresholds

V300, V301, S404, S405,
S406, S407, S408, S411,
S412, S424, S425, S426,
S427, 437, S439, S470*,
S471, S472, S473, S474*,
S475, S476*, S478, S479,
480, S481, S482*, S483*,
S484*, S485*, S486*, S487*,
S488*, S489*, S490*, S498*

**suffix insert can be v-vinyl,
u-polyurethane, n-neoprene,
s-silicone, or pr-polyprene*

1. Measure door sill (frame width at bottom) and cut the threshold to extend the full width of the opening.
2. Notch the threshold sides if necessary to accommodate the side jamb stops.
3. Fasten on threshold to the sill with screws provided.
4. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested
Gasketing Materials for Fire
Doors. Intended for Application
to/with listed steel frames
and/or classified steel covered
composite, hollow metal type
fire doors rated up to 3 hours,
wood and plastic covered
composite type fire doors rated
up to 1-1/2 hours, and wood
core type fire doors rated up
to 20 minutes.

Meets UL10B, UL10C and
UBC 7-2 (1997) Category J.

17L5

9903