



Box 459 - Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823

**Perimeter- Smoke & Draft
Hardware Compatible
653, 655, 657, 755,
757, 775, 855, 875**

1. Measure door frame head.

2. Cut the Part to extend the full width of the opening, leaving the gasketing material slightly longer than the metal retainer for a snug seal.

NOTE: Side pieces have slotted holes. Top piece has no holes and is to be drilled at the job. Closers and holders can be mounted on the part.

3. With the use of a self-closing mechanism, allow the door to close.

4. Position the gasketing material with light pressure against the door.

5. Attach with the sheet metal screws provided, locating the screw in the hole or in the center of the slot. The slot permits room for adjustment later. Do not tighten the screws until all gasketing is in place.

6. Measure the door frame sides. Attach the two side jambs in the same manner as the door frame head using the 2 thru 5 above instructions.

7. Tighten all the screws.

8. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Also Classified in accordance with UBC 7-2, Fire Tests of Door Assemblies(1997). Meets UL10B, UL10C and UBC 7-2 (1997) Category J. UBC 7-2(1997)part 2 Category H Can use on 'S' Labeled doors.
17L5 9903

