



Box 459 - Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823

Perimeter-Smoke & Draft

918, 934, 956, 957, 958,
959, 961, 964, 967

1. Measure door frame head.

2. Slide the brush strip out of its aluminum retainer. Cut the brush to length with a WIRE CUTTER or PLIERS.

WARNING: Always cut the brush strip with a WIRE CUTTER or PLIERS. This is necessary to crimp the brush filaments in the galvanized retainer to keep them from falling out.

Then cut the aluminum retainer to the same length. Re-insert the brush into the aluminum retainer.

3. With the use of a self-closing mechanism, allow the door to close.

4. Position the part on the door stop with light pressure against the door.

5. Attach with the sheet metal screws provided, locating the screw in the center of the slotted holes in the aluminum retainer. This permits room for adjustment later. Do not tighten the screws until all gasketing is in place. (Note: Some parts will have round attachment holes due to the small size)

6. Measure the door frame sides. Attach the two side jambs in the same manner as the door frame head using the 2 thru 5 above instructions.

7. Tighten all the screws.

8. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Also Classified in accordance with UBC 7-2, Fire Tests of Door Assemblies(1997). Meets UL10B, UL10C and UBC 7-2 (1997) Category J. UBC 7-2(1997)part 2 Category H Can use on 'S' Labeled doors.
17L5 9903

